Installation and care

Passive styluses and replacement tips

Read before use and keep these instructions.

Intended use

Non-powered styluses and tips for compatible interactive displays; IR and capacitive technologies are not automatically interchangeable.

Use only the YIVO accessory specified for your device model, dimensions and mounting system. Keep the packaging or purchase record identifying the product and batch, if marked. These category instructions supplement the device manual; they do not confirm compatibility with every model. If instructions conflict or the part does not fit, stop and contact YIVO.

Before you start

Switch off the device, disconnect external power and prevent automatic or remote starting before replacement. Let moving parts stop. Isolate batteries or other energy sources as the device manufacturer directs; do not dismantle a built-in battery. Replace only user-serviceable parts. Internal electrical or structural repairs belong to a qualified service provider.

Installation

Check the display technology and tip type. Fit a replaceable tip only by its intended thread or clip, without glue or force. Check retention and a clean, smooth contact surface. Write with light pressure. Use magnetic storage only at the designated location and check that the stylus is secure.

> Loose tips and magnets are ingestion hazards. Do not dismantle magnets, throw the stylus or point it at a face. Children should use it under appropriate adult supervision. Stop if the tip exposes a hard core, scratches the screen or comes loose. Powered pens need their own electrical instructions.

Cleaning and storage

Passive styluses and replacement tips

Wipe with a soft cloth, following the screen manufacturer's cleaning advice. Keep tips free of grit and replace worn ones. Do not soak. Store spare tips away from small children.

Start with a soft, dry, lint-free cloth. For a removable, non-porous surface compatible with water, use a cloth lightly dampened with clean water, then dry naturally. Keep liquid out of openings and electrical contacts. Do not soak leather, foam, glued layers or unmarked filters. Avoid solvents, abrasives, bleach, steam and direct heat unless expressly permitted for the accessory and surface.

Warnings

Keep loose small parts, magnets and packaging away from small children and animals. Do not put parts in the mouth. If a magnet or button battery may have been swallowed, seek urgent medical help. Follow implanted-device manufacturers' advice around magnetic accessories. These parts are not toys.

Stop using a loose, cracked, deformed or damaged part, or if abnormal heat, noise, vibration, leakage or skin irritation occurs. Secure the device against restarting. Report safety issues to kontakt@yivo.pl and claims to reklamacje@yivo.pl, identifying the product, device model and problem; photos and an order number help. Seek emergency help for immediate danger.

Store clean and dry, away from heat and sunlight. Sort packaging and worn parts under local collection rules; protect sharp edges. Parts containing electronics or batteries require the appropriate separate collection. These instructions do not restrict statutory rights against the seller. Any commercial guarantee is additional.

Manufacturer and support

YIVO Sebastian Zając | ul. Zofii Nałkowskiej 16/E, 41-700 Ruda Śląska, Polska / Poland

kontakt@yivo.pl | reklamacje@yivo.pl | https://yivo.pl/wsparcie/