

Installation and care

Headphone pads, headbands and covers

Read before use and keep these instructions.

Intended use

Ear pads, foam cushions, headband padding, adapters and hygiene covers.

Use only the YIVO accessory specified for your device model, dimensions and mounting system. Keep the packaging or purchase record identifying the product and batch, if marked. These category instructions supplement the device manual; they do not confirm compatibility with every model. If instructions conflict or the part does not fit, stop and contact YIVO.

Before you start

Switch off the device, disconnect external power and prevent automatic or remote starting before replacement. Let moving parts stop. Isolate batteries or other energy sources as the device manufacturer directs; do not dismantle a built-in battery. Replace only user-serviceable parts. Internal electrical or structural repairs belong to a qualified service provider.

Installation

Check size, left/right orientation and attachment method. Release the old pad without pulling wires. Retain only adapters intended for reuse. Seat the mounting lip evenly in the groove or close all clips; for adhesive versions follow the adhesive section. Fit covers without blocking sound openings, sensors or microphones. Begin listening at low volume.

Do not force-fit parts, stretch a headband over objects or open battery compartments. Poor attachment or altered sealing can affect sound and noise cancellation. Stop for pressure, irritation, exposed sharp parts or loose padding.

Cleaning and storage

Headphone pads, headbands and covers

Wipe gently and keep foam and glued seams dry. Do not soak leather or synthetic leather; use no unverified leather treatment. Wash fabric covers only if marked washable. Let dry naturally without squeezing or direct heat.

Start with a soft, dry, lint-free cloth. For a removable, non-porous surface compatible with water, use a cloth lightly dampened with clean water, then dry naturally. Keep liquid out of openings and electrical contacts. Do not soak leather, foam, glued layers or unmarked filters. Avoid solvents, abrasives, bleach, steam and direct heat unless expressly permitted for the accessory and surface.

Adhesive parts: dry-fit first. Carefully remove old adhesive without damaging the surface; use a cleaning agent only if compatible with its finish. Let the surface dry completely. Remove the release liner, avoid touching the adhesive, align and press evenly. Follow any supplied bonding-time instructions. No universal curing time applies. If an edge lifts or the part moves, stop use; do not add an unknown glue or heat the device.

Warnings

Keep loose small parts, magnets and packaging away from small children and animals. Do not put parts in the mouth. If a magnet or button battery may have been swallowed, seek urgent medical help. Follow implanted-device manufacturers' advice around magnetic accessories. These parts are not toys.

Stop using a loose, cracked, deformed or damaged part, or if abnormal heat, noise, vibration, leakage or skin irritation occurs. Secure the device against restarting. Report safety issues to kontakt@yivo.pl and claims to reklamacje@yivo.pl, identifying the product, device model and problem; photos and an order number help. Seek emergency help for immediate danger.

Store clean and dry, away from heat and sunlight. Sort packaging and worn parts under local collection rules; protect sharp edges. Parts containing electronics or batteries require the appropriate separate collection. These instructions do not restrict statutory rights against the seller. Any commercial guarantee is additional.

Manufacturer and support

YIVO Sebastian Zajac | ul. Zofii Nałkowskiej 16/E, 41-700 Ruda Śląska, Polska / Poland

kontakt@yivo.pl | reklamacje@yivo.pl | <https://yivo.pl/wsparcie/>