

Installation and care

Ear tips and in-ear headphone covers

Read before use and keep these instructions.

Intended use

Replaceable silicone or foam ear tips and compatible in-ear covers.

Use only the YIVO accessory specified for your device model, dimensions and mounting system. Keep the packaging or purchase record identifying the product and batch, if marked. These category instructions supplement the device manual; they do not confirm compatibility with every model. If instructions conflict or the part does not fit, stop and contact YIVO.

Before you start

Switch off the device, disconnect external power and prevent automatic or remote starting before replacement. Let moving parts stop. Isolate batteries or other energy sources as the device manufacturer directs; do not dismantle a built-in battery. Replace only user-serviceable parts. Internal electrical or structural repairs belong to a qualified service provider.

Installation

Choose the correct connector and a comfortable size. Hold the old tip at its base and remove as the headphone manual directs. Fit the new tip fully without blocking the sound outlet; gently check retention before every use. Insert without force and start at low volume. Confirm that charging cases close freely.

A loose tip can remain in the ear or be swallowed. If stuck in the ear, do not use sharp tools; seek medical assistance. Stop for pain or irritation. Do not share unclean tips. Noise isolation can reduce awareness of traffic and other hazards.

Cleaning and storage

Ear tips and in-ear headphone covers

Clean removed tips according to material. Rinse silicone only when permitted and dry fully before refitting. Do not soak foam or use solvents. Replace torn, hardened or poorly fitting tips.

Start with a soft, dry, lint-free cloth. For a removable, non-porous surface compatible with water, use a cloth lightly dampened with clean water, then dry naturally. Keep liquid out of openings and electrical contacts. Do not soak leather, foam, glued layers or unmarked filters. Avoid solvents, abrasives, bleach, steam and direct heat unless expressly permitted for the accessory and surface.

Warnings

Keep loose small parts, magnets and packaging away from small children and animals. Do not put parts in the mouth. If a magnet or button battery may have been swallowed, seek urgent medical help. Follow implanted-device manufacturers' advice around magnetic accessories. These parts are not toys.

Stop using a loose, cracked, deformed or damaged part, or if abnormal heat, noise, vibration, leakage or skin irritation occurs. Secure the device against restarting. Report safety issues to kontakt@yivo.pl and claims to reklamacje@yivo.pl, identifying the product, device model and problem; photos and an order number help. Seek emergency help for immediate danger.

Store clean and dry, away from heat and sunlight. Sort packaging and worn parts under local collection rules; protect sharp edges. Parts containing electronics or batteries require the appropriate separate collection. These instructions do not restrict statutory rights against the seller. Any commercial guarantee is additional.

Manufacturer and support

YIVO Sebastian Zajac | ul. Zofii Nałkowskiej 16/E, 41-700 Ruda Śląska, Polska / Poland

kontakt@yivo.pl | reklamacje@yivo.pl | <https://yivo.pl/wsparcie/>