

Installation and care

Air purifier replacement filters

Read before use and keep these instructions.

Intended use

Replaceable filter cartridges for the specified air purifier; not respiratory protective equipment.

Use only the YIVO accessory specified for your device model, dimensions and mounting system. Keep the packaging or purchase record identifying the product and batch, if marked. These category instructions supplement the device manual; they do not confirm compatibility with every model. If instructions conflict or the part does not fit, stop and contact YIVO.

Installation

Unplug the purifier. Open its service cover and remove the old filter without spreading dust. Remove all transport wrapping from the new filter. Match the airflow direction, seals and locating features. Close the cover and reset the filter indicator only after replacement, as the device manual directs.

Do not run without the required filter or with packaging still attached. Do not wash HEPA or carbon media unless expressly marked washable. Do not add fragrance or chemicals. A filter does not remove every gas or replace ventilation; no filtration class is implied without product-specific evidence.

Cleaning and storage

Air purifier replacement filters

Clean only permitted pre-filters by their instructions. Keep replacement filters sealed, dry and undeformed. Replace damaged, saturated or persistently odorous media; follow the device indicator, conditions of use and instructions. Avoid inhaling released dust.

Start with a soft, dry, lint-free cloth. For a removable, non-porous surface compatible with water, use a cloth lightly dampened with clean water, then dry naturally. Keep liquid out of openings and electrical contacts. Do not soak leather, foam, glued layers or unmarked filters. Avoid solvents, abrasives, bleach, steam and direct heat unless expressly permitted for the accessory and surface.

Warnings

Keep loose small parts, magnets and packaging away from small children and animals. Do not put parts in the mouth. If a magnet or button battery may have been swallowed, seek urgent medical help. Follow implanted-device manufacturers' advice around magnetic accessories. These parts are not toys.

Stop using a loose, cracked, deformed or damaged part, or if abnormal heat, noise, vibration, leakage or skin irritation occurs. Secure the device against restarting. Report safety issues to kontakt@yivo.pl and claims to reklamacje@yivo.pl, identifying the product, device model and problem; photos and an order number help. Seek emergency help for immediate danger.

Store clean and dry, away from heat and sunlight. Sort packaging and worn parts under local collection rules; protect sharp edges. Parts containing electronics or batteries require the appropriate separate collection. These instructions do not restrict statutory rights against the seller. Any commercial guarantee is additional.

Manufacturer and support

YIVO Sebastian Zajac | ul. Zofii Nałkowskiej 16/E, 41-700 Ruda Śląska, Polska / Poland

kontakt@yivo.pl | reklamacje@yivo.pl | <https://yivo.pl/wsparcie/>