

Installation and care

Vacuum cleaners and cleaning robots

Read before use and keep these instructions.

Intended use

Brushes, rollers, filters, bags, mop pads, bins, wheels and other external replacement parts.

Use only the YIVO accessory specified for your device model, dimensions and mounting system. Keep the packaging or purchase record identifying the product and batch, if marked. These category instructions supplement the device manual; they do not confirm compatibility with every model. If instructions conflict or the part does not fit, stop and contact YIVO.

Before you start

Switch off the device, disconnect external power and prevent automatic or remote starting before replacement. Let moving parts stop. Isolate batteries or other energy sources as the device manufacturer directs; do not dismantle a built-in battery. Replace only user-serviceable parts. Internal electrical or structural repairs belong to a qualified service provider.

Installation

Match the part and its orientation to the device manual. Open the service cover, remove the worn part by its retaining features and clear trapped debris. Seat the replacement fully; check latches, seals and covers. Replace parts as a set where required. Test with hands away from moving brushes.

Never run without required filters, bins or guards. Do not fit wet parts in dry air paths. Do not add foaming or corrosive agents to tanks. Stop for leaks, overheating or a jammed brush.

Cleaning and storage

Vacuum cleaners and cleaning robots

Remove hair and debris after isolating power. Wash only parts explicitly marked washable; let them dry fully before refitting. Replace torn filters, damaged shafts and leaking containers. Select maintenance frequency from condition and the device manual.

Start with a soft, dry, lint-free cloth. For a removable, non-porous surface compatible with water, use a cloth lightly dampened with clean water, then dry naturally. Keep liquid out of openings and electrical contacts. Do not soak leather, foam, glued layers or unmarked filters. Avoid solvents, abrasives, bleach, steam and direct heat unless expressly permitted for the accessory and surface.

Warnings

Keep loose small parts, magnets and packaging away from small children and animals. Do not put parts in the mouth. If a magnet or button battery may have been swallowed, seek urgent medical help. Follow implanted-device manufacturers' advice around magnetic accessories. These parts are not toys.

Stop using a loose, cracked, deformed or damaged part, or if abnormal heat, noise, vibration, leakage or skin irritation occurs. Secure the device against restarting. Report safety issues to kontakt@yivo.pl and claims to reklamacje@yivo.pl, identifying the product, device model and problem; photos and an order number help. Seek emergency help for immediate danger.

Store clean and dry, away from heat and sunlight. Sort packaging and worn parts under local collection rules; protect sharp edges. Parts containing electronics or batteries require the appropriate separate collection. These instructions do not restrict statutory rights against the seller. Any commercial guarantee is additional.

Manufacturer and support

YIVO Sebastian Zajac | ul. Zofii Nałkowskiej 16/E, 41-700 Ruda Śląska, Polska / Poland

kontakt@yivo.pl | reklamacje@yivo.pl | <https://yivo.pl/wsparcie/>